

# TIP OF THE WEEK

**MODEL** ..... **PC78US-10 – PC2000-8**  
**FEATURE** ..... **SWING LOCK**  
**STD/OPT** ..... **STANDARD**  
**SUGGESTED SETTING** ..... **JOB DEPENDENT**



When activated, the swing lock rocker switch engages a disc brake that mechanically prevents the upper structure from rotating. When the swing lock is activated, an activation icon is illuminated red in the monitor. The swing lock is either engaged (position B) or disengaged (position A).

***Swing Lock is generally used in tight work areas where swinging of the machine may result in damage to adjacent structures. It is also useful for holding the upper structure from rotating during transport or holding loads stationary when working on slopes.***

For additional information, please consult the Product Bulletin, Operator's Manual or Shop Manual.  
 Photos may include optional equipment.