

TIP OF THE WEEK

MODEL..... PC228USLC-10, PC308USLC-3, PC210LC-10,
PC490LC-11

FEATURE..... 3 Speed Travel

STD/OPT..... Standard

SUGGESTED SETTING.... Job Dependent

Travel speed icon in monitor

Travel Speed Button



The travel speed button changes travel speed range; low, medium or high. Each time the switch is pressed, the display changes Lo → Mi → Hi → Lo in sequence.

Travel speed selection always defaults to low speed at machine start. When traveling on soft ground or uphill, and increased track power is needed, the system automatically shifts down to low speed travel (Lo).

For faster travel speed, selecting medium or high travel can reduce time required to move long distances. In medium or high speed, the machine will automatically downshift and upshift as required based on load.

For additional information, please consult the Product Bulletin, operator's Manual or Shop Manual.
Photos may include optional equipment
KTIP 2015-42 REV:10/15

