

# TIP OF THE WEEK

MODEL.....	PC45MR-5 thru PC1250LC-8
FEATURE.....	Work Modes
STD/OPT.....	Standard
SUGGESTED SETTING....	Power Mode

Komatsu excavators are equipped with up to 6 work modes\* for changing machine performance characteristics to match machine application.

- P: P mode (for high performance operation)
- E: E mode (for light work and low fuel consumption)
- L: L mode (for lifting or fine control operation)
- B: B mode (One way flow for breaker operations)
- ATT/P: ATT/P mode (for operations of 2-way attachments such as crusher, etc.)
- ATT/E: ATT/E mode (for operations of 2-way attachments such as crushers with an emphasis of fuel consumption)

If light-load work is continued for more than 10 minutes in P or ATT/P modes, an E mode recommendation message will be displayed recommending changing work mode to E for reduced fuel consumption. The monitor can be set up to automatically select a specific work mode at machine start up or remember the last setting at machine shut down.

Power modes can improve machine efficiency by matching machine performance to the work being done. Using the proper work mode can improve machine productivity or save fuel.

Power Mode icon in monitor

Work Mode Selector



For additional information, please consult the Product Bulletin, operator's Manual or Shop Manual.  
Photos may include optional equipment  
KTIP 2015-43                      REV:11/15