

TIP OF THE WEEK


MODELD37/D39/D61-23, D61-24
 FEATUREOPERATOR PREFERENCES
 STD / OPTSTANDARD
 SUGGESTED SETTINGOPERATION DEPENDENT

Operator Preferences can be easily selected in the HST monitor, saved to memory, then recalled later for up to 5 operators.

To match jobsite work conditions, the operator can custom set 10 dozer work modes and save them to the monitor. The settings can be recalled from memory, eliminating the need to re-select the settings.

Press F1 to start the select & save process

Select 10 work mode preferences then save as a M1-M5.



Item	Mode	Adjustments
1	Working Mode	High Engine Idle Speed / Power / Economy
2	Gear Shift Mode	Quick Shift (3) / Variable (20)
3	Pedal Mode	Decelerator Model / Brake Mode
4	Reverse Travel Speed	-1 / 0 / +1 / +2 / +3 / (5 Levels)
5	Load Graph Display	ON / OFF
6	Blade Fine Control	Fast / Normal / Fine
7	Steering	Normal / Fine
8	1st Travel Speed	-2 / -1 / 0 / +1 / +2 (5 Levels)
9	2nd Travel Speed	-2 / -1 / 0 / +1 / +2 (5 Levels)
10	3rd Travel Speed	-2 / -1 / 0 (0 Levels)

Note: Table of operator preferences are shown for D61-24. The -23 dozers are similar.

For additional information, please consult the Product Bulletin, Operator's Manual or Shop Manual. Photos may include optional equipment.



Copyright 2016 Komatsu America Corp. All rights reserved