

TIP OF THE WEEK

MODEL WA380-7/8 → WA500-7/8
 FEATURE Transmission Cut-off Switch
 STD / OPT Standard
 SUGGESTED SETTING ON



The Transmission Cut-Off Switch has two functions, 1) ON/OFF and 2) setting the brake pedal position for disconnecting the transmission. Pressing the top ([A] position) of this momentary switch toggles the transmission cut-off function ON or OFF. Pressing the bottom ([B] position) sets the transmission disconnect position.

TOP Position [A]:

ON: When pressing the brake pedal, the machine shifts to Neutral before the brakes are applied.

OFF: The pedal acts as a brake only and will not shift into Neutral.

BOTTOM Position [B]:

This switch position allows the operator to set the angle at which the brake pedal shifts the machine to Neutral. This can make the pedal feel more or less sensitive based on operator preference.

The Transmission Cut-off Switch allows the operator to set both the function of the brake pedal (Neutral or Brake only), as well as the angle at which it activates.

For additional information, please consult the Product Bulletin, Operator's Manual or Shop Manual. Photos may include optional equipment.

